# TOP AND CONSOLE PARTS

ELECTRIC DRYER

**For Model: 3RAWZ480ESQ0**
**(White)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

**For Model: 3RAWZ480ESQ0**
**(White)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Literature Parts |
| | 8545902 | Label, Wiring Diagram |
| | 8577079 | Use & Care Guide |
| | 8563878 | Installation Instructions |
| | 8315975 | Installation & User Guide |
| 2 | 8519251 | Top |
| 3 | W10110980 | Harness, Main |
| 4 | W10118062 | Panel, Console (Includes Illus. 13, 14, 15, 17, 18 & 19) |
| 5 | 3394427 | Clip, Harness |
| 6 | W10118067 | Bracket, Console |
| 7 | 353424 | Connector, Sensor |
| 8 | 94614 | Terminal |
| 9 | 3936144 | Plug, Terminal |
| 10 | 94613 | Terminal |
| 11 | W10080700 | Screw, 8−18 x 1/2 |
| 12 | W10080370 | Screw, 8−18 x 1/2 |
| 13 | 3980121 | Button, Push−To−Start |
| 14 | W10118063 | Bracket, Timer |
| 15 | W10118064 | Bracket, Switch Mounting |
| 16 | W10080930 | Screw, 8−18 x 1/2 |
| 17 | 3400981 | Medallion |
| 18 | 3956540 | Console, Center |
| 19 | 3400238 | Screw, 2−28 x 1/2 |
| 20 | W10116280 | Timer |
| 21 | 3951198 | Fuse |
| 22 | W10080820 | Screw, 8−18 x 5/16 |
| 23 | 3980421 | Spacer Plate (Timer) |
| 24 | 8316076 | Switch, Wrinkle Guard |
| 25 | 8522378 | Buzzer, Mini |
| 26 | W10112668 | Switch, Push−To−Start |
| 27 | 3399642 | Switch, Temperature |
| 28 | W10110978 | Harness, Console |
| 29 | 3347243 | Connector, 6−Circuit |
| 30 | 3397269 | Connector, Timer |
| 31 | 3401144 | Connector, (PTS Relay) |
| 32 | 692997 | Connector |
| 33 | 3957756 | Knob, Timer Assembly |
| 34 | 3957803 | Knob, Control (2) |
| 35 | 3980339 | Shield, Drip |
| 36 | 688805 | Spring, Clip |

# CABINET PARTS

**For Model: 3RAWZ480ESQ0**
**(White)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

**For Model: 3RAWZ480ESQ0**
**(White)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | W10119283 | Cover, Terminal Block |
| 2 | 98139 | Screw, 8−32 x 5/16 |
| 3 | 697776 | Screw, 10−32 x 5/8 (Ground) |
| 4 | 3397659 | Block, Terminal |
| 5 | 8318457 | Switch, Broken Belt |
| 6 | 8521947 | Dry Rack (Top) |
| 7 | 8578437 | Panel, Side (L.H.) |
| 8 | 3392100 | Foot, Dryer |
| | 279810 | Foot − Optional (Extended Length Package Of 2) (Not Included) |
| 9 | 660658 | Clamp, Motor (2) |
| 10 | 3387374 | Spring, Idler |
| 11 | W10080670 | Retainer, Idler |
| 12 | 697750 | Plug, Multivent |
| 13 | 3388672 | Pulley Assembly |
| 14 | 279318 | Terminal, Brass & Tinned (3) (Includes Illus. 33) |
| 15 | 8066120 | Lever, Snap Switch |
| 16 | 3394081 | Wire, Belt Switch |
| 17 | 8564132 | Sound Panel |
| 18 | 233520 | Washer, Thrust |
| 19 | 8543119 | Jumper, Door Switch (Includes Illus. #41) |
| 20 | 690997 | Tri Ring |
| 21 | 8066115 | Cover−Plate |
| 22 | 8529053 | Ramp, Door |
| 23 | 8521961 | Dry Rack Support |
| 24 | 8578450 | Panel, Side (R.H.) |
| 25 | 8521950 | Dry Rack Assembly |
| 26 | 3393657 | Restrainer, Belt |
| 27 | 3404470 | Motor, Assembly 50 HZ. |
| 29 | 3402548 | Pulley 50 HZ. |
| 30 | 3387610 | Belt, Drive |
| 31 | 8541503 | Kit, Stack Assembly |
| 32 | W10119309 | Bracket, Motor |
| 33 | 279393 | Terminal Block Screw Kit (For Terminal Block) |
| 34 | 49026 | 4" − 90° Elbow |
| 35 | 8316644 | Clip, Strain Relief |
| 36 | 8563747 | Exhaust Pipe & Bracket |
| 37 | 8563750 | Exhaust Pipe (Short) |
| 38 | 8563749 | Exhaust Pipe (Long) |
| 39 | W10118754 | Idler Bracket |
| 41 | 8541808 | Switch, Door |
| 42 | W10118188 | Screw, 6−20 x 1 1/16 |
| 43 | W10080700 | Screw, 8−18 x 1/2 |
| 44 | 3387242 | Seal, Front Panel |
| 45 | W10080710 | Screw, 10−16 x 1/2 |
| 46 | 8519459 | Clip, Toe Panel |
| 47 | 340025 | Wire, Ground |
| 50 | W10119292 | Base, Cabinet |
| 51 | 8562162 | Front Panel |
| 52 | W10080240 | Strike, Door (2) |
| 53 | W10080280 | Screw, 8−18 x 3/8 |
| 56 | W10119274 | Bracket, Control |
| 61 | W10116271 | Toe, Panel |
| 62 | W10118075 | Panel, Rear |
| 63 | 692400 | Nut, Push−In |
| 64 | 3400097 | Screw, 10−24 x 3/8 |

## Optional Parts Not Included

### Dryer Exhaust Kit (For Side & Bottom Venting)

| | | |
|---|---|---|
| 66 | 279818 | White |

# BULKHEAD PARTS

**For Model: 3RAWZ480ESQ0**
**(White)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

**For Model: 3RAWZ480ESQ0**
**(White)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 8575324 | Shaft, R.H. Thread |
| 2 | W10080700 | Screw, 8−18 x 1/2 |
| 3 | 3394984 | Door, Lint Screen |
| 4 | 98139 | Screw, 8−32 x 5/16 |
| 5 | 697354 | Air Duct Assembly |
| 6 | 697813 | Seal, Outlet Housing |
| 7 | 697814 | Seal, Drum Front |
| 8 | W10080210 | Nut,3/8 x 16(R.H.) |
| 9 | 8066086 | Drum Hole Plug |
| 10 | 696302 | Shield, Exhaust |
| 12 | 8572105 | Clip, Exhaust Pipe |
| 13 | W10080820 | Screw, 8−18 x 5/16 |
| 14 | 3387749 | Heater Element |
| 15 | 279457 | Terminal Wire Kit (For Heater Element Wiring Harness Repair) |
| 16 | W10001120 | Nut, 3/8−16 (L.H.) |
| 17 | 3387809 | Bulkhead, Rear |
| 18 | W10080960 | Washer, Support |
| 19 | 8575325 | Shaft, L.H. Thread |
| 20 | 690997 | Ring, Tri |
| 21 | 8536973 | Roller, Support |
| 22 | W10119260 | Exhaust Pipe |
| 23 | 3394985 | Housing, Outlet |
| 24 | 8529007 | Plug, Rear Bulkhead |
| 25 | 8543082 | Complete Drum Assembly |
| 26 | W10080190 | Screw, 11−16 x 3/4 |
| 27 | 697694 | Seal, Drum |
| 28 | W10080400 | Screw, 8−18 x 1/2 |
| 29 | W10080280 | Screw, 8−18 x 3/8 |
| 30 | W10118335 | Channel Bracket, Rear Bulkhead (2) |
| 31 | W10118337 | Bracket, Upper Rear Bulkhead |
| 32 | W10080380 | Screw, 8−18 x 5/8 |
| 34 | W10080590 | Screw, 10−16 x 1/2 |
| 37 | 697772 | Wheel, Blower |
| 39 | 3394986 | Spring, Lint Screen Door |
| 42 | 3387137 | Thermistor |
| 44 | W10119255 | Housing, Blower |
| 45 | W10119263 | Lint Duct Assembly |
| 46 | 3392537 | Heater Box |
| 47 | 3977394 | Thermal Cut−Off (Includes Illus. 48) |
| 48 | 3390291 | Thermostat 250°F (121°C) |
| 50 | W10119253 | Bracket, Heater Box |
| 51 | W10080640 | Screw, 10−16 x 1 |
| 53 | 697693 | Baffle, Drum |
| 54 | 8519245 | Bulkhead, Front |
| 58 | 8299979 | Grill, Outlet |
| 60 | 697770 | Seal, Cover Plate |
| 64 | 8066170 | Lint, Screen |

# DOOR PARTS

**For Model: 3RAWZ480ESQ0**
**(White)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 8563855 | Plug, Strip |
| 2 | W10111142 | Door Hinge Assembly |
| 3 | 3980214 | Cover, Door Hinge |
| 4 | W10080840 | Screw, 8−18 x 5/8 |
| 5 | 342043 | Screw, 10−32 x 3/8 |
| 7 | 8559752 | Handle, Door |
| 8 | W10080770 | Screw, 1/4−20 x 1/2 |
| 9 | 8519374 | Plug, Door Handle (2) |
| 10 | W10118207 | Door Assembly (Inner) (Includes Illus. 14 & 15) |
| 11 | 355515 | Screw, 8−18 x 11/16 |
| 12 | 3980213 | Door, Outer |
| 13 | 8545879 | Window |
| 14 | 3389441 | Door Catch Assembly (Top) |
| 15 | 690081 | Door Catch Assembly (Bottom) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

**For Model: 3RAWZ480ESQ0**
**(White)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| | | **PAINT, TOUCH−UP (1/2oz.)** |
| | 72017 | White |
| | | **PAINT, PRESSURIZED SPRAY (12 oz.)** |
| | 350930 | White |
| | 350938 | Primer, Gray |
| | | **PAINT, BULK (1 qt.)** |
| | 799344 | White (Uncut) |
| | | **ACCESSORY PARTS** |
| | 8529894 | Hold Down Kit |